

The Vexcel UltraCam Large-Format Digital Aerial Camera System

and

NAIP

Salt Lake City, 16 November 2004

Joe Thurgood

www.vexcel.com



- 1. The Vexcel UltraCam
 - Photogrammetric Design
 - Image Quality
- 2. Operating with the UltraCam
- 3. Image Products
 - Pan-sharpening
 - Film vs. digital
- 4. UltraCam-based NAIP Products
 - Initial results



The Vexcel UltraCam Large-Format Digital Aerial Camera

Overview



What is the UltraCam?

- 86 MegaPixel Frame Camera
- Black-and-White, Color and False Color Infrared Images

- Frame imagery compatible with standard photogrammetry software
- 1 frame per second



UltraCam System Components



Sensor Unit Storage & Computing Unit



System Components - Detail



Storage/Computing Unit





Individual CPU/Storage




Camera Geometry

www.vexcel.com






Traditional Film Geometry






Master Cone Geometry



www.vexcel.com




Additional Camera Cone - 1



1st Slave Cone with 2 Area Array CCDs




Additional Camera Cone - 2




2nd Slave Cone with 2 Area Array CCDs



Additional Camera Cone - 3



3rd Slave Cone with 1 Area Array CCD






Tie Points at overlapping areas




11,500 pixels (x)

Flight Direction


Image Geometry is based on the Master Cone with its 4 CCDs








For each full image,






For each full image, the UltraCam exposes all






For each full image, the UltraCam exposes all subframes





For each full image, the UltraCam exposes all subframes from the same effective camera station





For each full image, the UltraCam exposes all subframes from the same effective camera station

Producing a single central perspective with no differential parallax






Multispectral Imaging



Cone # 5,6,7,8, each 1 Sensor Element



4 Slave Cones with 1 Area Array CCD capture multispectral data

Single Image:

- Seamless 11,500 by 7,500 pixels
- Calibrated and interior oriented
- < ± 2 µm geometric accuracy
- 86 MPixels x 5 (= pan + 4 bands)
- > 1 frame / second


Standard Full UltraCam Image



- 14-bit analog/digital conversion
 - Low system noise (~1-1.5 bits)
 - Produces full 12-bit image content per band
- Increased dynamic range permits
 - Longer useful flying windows
 - More useful manipulation of the image data



Low Light Conditions








High Resolution Pan





+ true color RGB













Universal Imaging Capabilities

UltraCam Digital: GSD 8 cm



Imagery courtesy of PASCO Corporation, Japan




UltraCam Operations

www.vexcel.com




Imaging Geometry – 1





Imaging Geometry - 2







Recording





Pan-sharpening

www.vexcel.com



- Ratio of ~1:3.5 between pan and multispectral data in UltraCam
- Permits meaningful information content in all bands
 - Otherwise must compromise dynamic range within spectral bands, or ability to collect all 5 bands simultaneously
- Color vs. Texture
 - The visual system has many more panchromatic cones than color rods
 - Visually we focus on texture and edge detail
 - Automated image analysis / computervision also focuses on texture and edge detail



Digital vs. Film

Comparison of digital pansharpened color and color film

www.vexcel.com



Visual quality

Ability to match

Accuracy of matching

Effective resolution



Visual Quality

www.vexcel.com





Analog stereo pair:










Digital stereo pair:







Test flights: Morrison by Sanborn

Digital: UltraCam_D 00250 & 00251rgb.tif

Film:

anlglo0306 & anlglo0406.tif @ 14 µm



Analog stereo pair:







• Digital stereo pair:









Data set 2:




analog

digital

www.vexcel.com




Analog / scanned film



Imagery courtesy of Sanborn Map Company





www.vexcel.com





• Data set 2:





analog digital




Ability to Stereo-Match (for AT and DEM Extraction)


Comparison of film and pansharpened digital color



Stereo matching - FILM

Test 1, data set 1: FILM






pan: ± 0.33 pixel

green: ± 0.30 pixel



Stereo matching - DIGITAL

Test 1, data set 1: Digital



Panchromatic: ± 0.17 pixel


Pansharpened green: ± 0.17 pixel




- Tiepoints successfully matched:
 - -80% digital
 - 26% scanned film
- Digital matching is tighter
 - Subpixel accuracy almost twice as high
- Reflection of higher information content, lower noise



Stereo matching in smooth areas





analog digital

In the film image the matching in homogeneous regions (road, parking lot, roof) fails and no match points can be collected.



Effective Resolution

Comparing film and (pansharpened) digital color


www.vexcel.com



- By examining edge detail in images, we can determine a standard measure of resolution: ability to discriminate fine detail
- Method:
 - Fit curve to measured edge profiles
 - First derivative (slope) gives us an edge response
 - Full Width of edge response at Half Height (FWHH) is measure of resolution

Edge Response


• Synthetic edge



Blue: measured profile

Red: fitted edge

function



Blue: derived point spread function


Red: standard measure

of resolution




Measured Edge Profiles

Test 1: Pedestrian crossing



Digital: UltraCam



Analog Film, @ 20µm



Measured Edge Profiles

 Test 2: Shadows of houses on the road







digital



Measured Edge Profiles

 Test 3: Morrison, edges from road to sidewalk







digital


www.vexcel.com

Imagery courtesy of Sanborn Map Company



Edge Profiles (normalized)

Data set 2: Morrison




analog

digital




Edge Response: Test Results







Edge Response





Measure of Resolution

- Analog:
 - Resolution: 1.8-2.9 pixels
- Digital:
 - Resolution: 1.1 1.9 pixels
- Digital superior by factor of 1.5
- No appreciable difference in resolving power (<0.05 pixels) between
 - digital pan
 - pan-sharpened color band
- Pan-sharpened superior to film in all cases



Digital vs. Film Image Quality

Visual quality:

- Better apparent resolution when scanned pixel size (film) is equal to ground pixel size (digital)
- Clearer detail and texture apparent in smooth (homogeneous) areas

Information content:

- More complete matching even in smooth areas
- More accurate matching
- Edge detail / measured resolving power is superior



UltraCam-based NAIP Products

Initial Test Results

www.vexcel.com




Side-by-side Comparison

- Film:
 - Analog Camera: Leica RC30
 - Flying height: 20,000 feet
 - Scanned using Z/I PhotoScan @21 microns
- Digital:
 - Vexcel UltraCam
 - Flying height: 24,000 feet
- Location:
 - Greeley, Colorado
- Date:
 - November 2004



Collection Geometry





Film-based DOQQ



Imagery courtesy of Sanborn Map Company



UltraCam-based DOQQ



Note:image seams






Side by side comparison - 1



Imagery courtesy of Sanborn Map Company



Side-by-side comparison - 2



Imagery courtesy of Sanborn Map Company



Side by side comparison - 3





Conclusions

www.vexcel.com



Vexcel UltraCam

- UltraCam designed for maximum geometric and radiometric quality
- The UltraCam produces pan-sharpened products still superior to scanned film based on subjective and quantitative analysis
- Increased information content permits wide range of additional, automated applications and analysis
- Production workflow can be streamlined only with fully-digital workflow



Acknowledgements

- Sanborn Map Company
 - UltraCam flight operations, production and analysis
 - Film imagery

- Roland Perko, Technical University Graz
 - Film / digital / pansharpening imagery analysis



Thank You

Joe Thurgood
Director, Aerial Photogrammetry Products
Vexcel Corporation, Boulder Colorado

Email: joe.thurgood@vexcel.com

Phone: +1.303.583.0250